



Hipstreet Phoenix MP3 Player Battery Replacement

This guide will accomplish replacing the battery in the Hipstreet Phoenix.

Written By: Kaleb White



INTRODUCTION


I will demonstrate how to replace the non-replacable battery in the Hipstreet Phoenix. Be careful, as it may be swollen.



TOOLS:

- [Eyeglasses Repair Kit Screwdriver Size #00](#)
(1)
 - [Utility Scissors](#) (1)
-

Step 1 — Preparation,




- OK. So here we go. This guide will demonstrate how to replace the battery in the device shown. And sorry for the bad image quality, my camera lens is dirty.

Step 2 — SHUT OFF YOUR DEVICE!!!



- If you don't, you could have a lithium ion fire, and that's no good.

Step 3 — Take off the casing



- OK. Mine suffered this, and it still works. That's for the record. You will need a eyeglass screwdriver, or if the battery already puffed up, you don't need it or then you have a step 2 case, and nobody wants that.

Step 4 — Be careful, or you can have a step 2



- Be VERY VERY VERY VERY VERY careful. You now have to remove the battery with scissors. Cut the leads. I don't have a picture, so imagine step 3's image having a battery, and cut the 2 leads with scissors.

Step 5 — Reseal case and you're done!



- On mine, I used one of the pads used to secure the battery to hold the loose leads. You now have to reseal the case; use that screwdriver. If you did already; and it's currently on your desk being a 40 dollar paperweight, you are done! Now go hook it up to a computer and transfer music files!
Note: you need to be careful, if your (look at line 2)
- (continued from line 1) cable's tip is bent, you have to be careful.

You are done fixing it! Be happy! (Note: you need a cell phone charger tube battery to use it as a portable)

This document was last generated on 2017-06-24 02:27:49 AM.